




Quick Start

Using the Standard Routines in Animated Lighting Controllers


1. Connecting the Lights

- A. Use the Standard Routine Diagram to locate the show that most resembles your lighting setup.
- B. Connect your lights to the Animated Lighting controller according to the Standard Routine Diagram that you have selected.




2. Selecting a Standard Routine

- A. Find the Show Selection value for your lighting setup on the Standard Routine Diagram.
- B. Locate the Program Selection Dial on the Monster Brain as shown.
- C. Turn this dial to the Show Selection value from the diagram. (1 - F)



3. Turning on the Lights

Connect your Animated Lighting controller to any standard AC outlet. Your display will light up instantly.



4. Selecting a different Standard Routine

- A. Rotate the Program Selection Dial to the new Show Selection value.
- B. Press the Reset button on the Monster Brain to start the selected show.
- C. Your selected show will start instantly.



Quick Start

Selecting the Show for Your Displays Configuration

User Programmable

Show 0: Not Used (User Programmable)

Single Color Shows

Show 1: 1 Color - 8 Channels - Setup A : Generic Layout

Show 2: 1 Color - 8 Channels - Setup B : Zone 1 - House Left; Zone 2 - House Right; Zone 3 - Windows, Doors; Zone 4 - Trees 1; Zone 5 - Trees 2; Zone 6 - Trees 3; Zone 7 - Trees 4; Zone 8 - Trees 5

Show 3: 1 Color - 16 Channels - Setup A : Generic Layout

Show 4: 1 Color - 16 Channels - Setup B : Zone 1 - House Left; Zone 2 - House Middle; Zone 3 - House Right; Zone 4 - Windows, Doors 1; Zone 5 - Windows, Doors 2; Zone 6 - Trees 1; Zone 7 - Trees 2; Zone 8 - Trees 3; Zone 9 - Zone 16 - Generic

2 Color Shows

Show 5: 2 Color - 8 Channels - Setup A : Zone 1 - House Left; Zone 2 - House Right; Zone 3 - Windows, Doors; Zone 4 - Trees

Show 6: 2 Color - 16 Channels - Setup A : Zone 1 - House Left; Zone 2 - House Middle; Zone 3 - House Right; Zone 4 - Windows 1; Zone 5 - Windows 2; Zone 6 - Trees 1; Zone 7 - Trees 2; Zone 8 - Lined Drive

Show 7: 2 Color - 16 Channels - Setup B : Zone 1 - House Left; Zone 2 - House Right; Zone 3 - Windows 1; Zone 4 - Windows 2; Zone 5 - Trees 1; Zone 6 - Trees 2; Zone 7 - Trees 3; Zone 8 - Trees 4

4 Color Shows

Show 8: 4 Color - 16 Channels - Setup A : Generic Layout

Show 9: 4 Color - 16 Channels - Setup B : Zone 1 - House Left; Zone 2 - House Right; Zone 3 - Windows; Zone 4 - Trees

Show A: 4 Color - 16 Channels - Setup C : Zone 1 - House; Zone 2 - Windows; Zone 3 - Shrubs Left; Zone 4 - Shrubs Right

Show B: 4 Color - 16 Channels - Setup D : Zone 1 - House; Zone 2 - Windows; Zone 3 - Shrubs Left; Zone 4 - Lined Drive

Show C: 4 Color - 32 Channels - Setup A : Zone 1 - House Left; Zone 2 - House Middle; Zone 3 - House Right; Zone 4 - Windows 1; Zone 5 - Windows 2; Zone 6 - Trees 1; Zone 7 - Trees 2; Zone 8 - Lined Drive

Show D: 4 Color - 32 Channels - Setup B : Zone 1 - House Left; Zone 2 - House Right; Zone 3 - Windows 1; Zone 4 - Windows 2; Zone 5 - Trees 1; Zone 6 - Trees 2; Zone 7 - Trees 3; Zone 8 - Trees 4

Show E: 4 Color - 48 Channels - Setup A : Zone 1 - House Left; Zone 2 - House Middle; Zone 3 - House Right; Zone 4 - Windows 1; Zone 5 - Windows 2; Zone 6 - Windows 3; Zone 7 - Windows 4; Zone 8 - Trees 1; Zone 9 - Trees 2; Zone 10 - Trees 3; Zone 11 - Trees 4; Zone 12 - Lined Drive

Show F: 4 Color - 48 Channels - Setup B : Zone 1 - House 1; Zone 2 - House 2; Zone 3 - House 3; Zone 4 - House 4; Zone 5 - Windows 1; Zone 6 - Windows 2; Zone 7 - Trees 1; Zone 8 - Trees 2; Zone 9 - Trees 3; Zone 10 - Trees 4; Zone 11 - Trees 5; Zone 12 - Lined Drive

NOTE: For best results, connect your lights to the control box in numerical order from left to right. When using multiple colors, connect them to the controller by four color zones using the same color pattern.