

GREATEST STORY EVER TOLD – MANGER & STAR INSTALLATION GUIDE

- The Lighting Channels that make up the Manger
 - O Channel 2: Manger Structure
 - O Channel 3: Joseph
 - o Channel 4: Mary
 - Channel 5: Baby Jesus
 - Channel 10: Glory of God (Strobe strings on Manger)
 - O Channel 11: Star
- Tools Needed for this Installation
 - o 9/16" Wrench or Socket
 - O Rubber Mallet or Hammer with Wood Block
- RECOMMENDED NUMBER OF PEOPLE FOR INSTALLATION: 4 ADULTS

STEP 1: Bring out the components for Channel 2 (Manger Structure) and Channel 11 (Star)





NOTE: Channel 2 (Manger Structure has the following components:

- Vertical pieces ("Left" and "Right" as you are looking at the Manger Structure with Feet
- Horizontal pieces ("Left" and "Right" as you are looking at the Manger Structure
- Manger Back Support with Foot

NOTE: Channel 11 (Star) has only one piece but it is attached to the Manger Structure





STEP 2: Have the light strings facing down on the ground. As you raise up the components the lights will be facing forward.

STEP 3: Plug in the Star to electrical power. Make sure it is working BEFORE raising the Star into the air





STEP 4: Assemble the top of the Manger Structure. NOTE: You will need Qty. 2 3/8" nuts to complete this (there are bolts welded on to the Manger Structure pieces

STEP 5: Connect the light strings together for the Manger Structure and turn them on BEFORE raising the Manger Structure into the air. This is Channel 2 of the Greatest Story display





STEP 6: On the Horizontal sections (Left and Right) of the Star Structure there is also one "Strobe String" on both the Left and Right side. Turn them on BEFORE raising the Manger Structure into the air.

IMPORTANT NOTE: The Strobe Strings are a separate lighting channel from the lights on the four parts of the Manger. The strings associated with the Manger is Lighting channel # 2. You will note that the bulbs on these strings are globes (round). The strings associated with the Glory of God are Mini-Light strings (Channel 10). They must be connected to different lighting channels in the Greatest Story light controller.

STEP 7: Attach the vertical pieces (the "legs") of the Manger Structure (Left and Right - marked). IMPORTANT NOTE: You will need a 3/8" bolt for each side (the legs are marked "Left" and" Right"









STEP 8: Make sure all light strings are turned on and working on the Manger Structure and the Star before raising the structure up into the air

STEP 9: Attach the Manger Back Support to the Manger

STEP 10: Attach the Star to the Manger Back Support.

IMPORTANT NOTE!! This is where you will need the Rubber Mallet or a hammer and small piece of wood. The Star is a tight fit on the Manger Back Support and you need to use either the Mallet or hammer and small piece of wood to make the tight fit







STEP 11: Put the feet on to the Vertical pieces (" the legs"). NOTE: You want to do this now because it is easier to slide on the feet now as opposed to when you stand up the Manger Structure and the Star





STEP 12: Put on the Manger Back Foot and use 2 PEOPLE to do this. IMPORTANT NOTE: Be VERY careful not to bend the Manger Back Support







STEP 13: YOU NEED 3 PEOPLE MINIMUM FOR THIS STEP (watch video)

STEP 14: Put in Stakes (connected to the stranded wire/aircraft cable). NOTE: There are a total of 4 of these. Two in the front and 2 in the back. These cables are 16' in length from the manger to the ground. IMPORTANT TIP: If the area where you are placing the Manger is uneven (sloping), put in the stakes first that is on the "uphill side".





SUGGESTION: We suggest you use "Safety Tape" or "Flag Tape" on each stranded wire (all 4). We suggest you place tape at eye level and knee level to prevent tripping





STEP 15: Stake down all the feet (Left, Right and Back). Install the stakes at an angle to help support the feet.



